

High Pressure Carbon Dioxide

Discharge Indicator

Description

The system discharge indicator is used to visually indicate, at a remote location, when the carbon dioxide system has discharged. Pressure from the system is piped to the discharge indicator with 1/4 in. piping. When the system discharges, pressure operates a piston in the indicator which pushes off a cover plate and exposes the wording "System Discharged."

Shipping Assembly Part No.	Description
40765	Discharge indicator

Component	Material	Thread Size/Type	Approvals
Discharge Indicator	Housing: Bronze Piston: Stainless Steel	1/4 in. NPT Female	UL (EX-2968); Listed for use with FM Approved systems

